



J. ROCKETT AUDIO DESIGNS



Controls

- **Level:** Turn right to increase the level, turn left to decrease it.
- **Gain:** Turn right to increase the gain, turn left to decrease it.
- **Accent:** Turn right to increase the accent focus, turn left to decrease it.


Settings

Use the level control maxed and then feather in the gain control to get an excellent clean boost. Lowering the gain level creates a remarkable clean boost or increase it to put a bit of hair on the note. Increasing the gain gives you very bluesy/country type drive tones or you can crank it all the way up for smooth “Dumble” like sounds! The accent control does not control tone. It should be used to accent frequency focus in order to find that “sweet” midrange tone.

All J. Rockett Audio Designs pedals operate off of the standard BOSS type 9 volt adapter or a single 9 volt battery. The power input is a 5.5 mm x 2.1 mm jack with the positive voltage on the outer sleeve. Using an external power supply will automatically disconnect the battery. Disconnect the input jack to preserve battery life when not in use or when not used with an appropriate, external power supply.

Power Supply

All J. Rockett Audio Designs pedals operate off of the standard BOSS type 9 volt adapter or a single 9 volt battery. The power input is a 5.5 mm x 2.1 mm jack with the positive voltage on the outer sleeve. Using an external power supply will automatically disconnect the battery. Disconnect the input jack to preserve battery life when not in use or when not used with an appropriate, external power supply.



2.1mm x 5.5 mm tip/negative plug

Warranty

J. Rockett Audio Designs LLC will repair or replace, at its discretion, defective workmanship or materials on all new J. Rockett Audio Designs products directly or through the selling dealer or an authorized service technician for one year from the date of purchase at no cost to the original purchaser. Repair and replacement parts installed will be warranted for the unexpired portion of the original warranty term.

Before sending a product in for repair, please contact us at chris@rockettpedals.com or jay@rockettpedals.com or call us at 760-419-1345.

This warranty does not cover shipping costs, product appearance or damages caused by accident, abuse, misuse or alteration. A dated sales slip or order number (issued by a tech, dealer or J. Rockett Audio Designs) must accompany a product being returned for warranty service. Repairs without a return authorization number will be refused. Please allow four (4) weeks for warranty service. For more information please contact J. Rockett Audio Designs via our website at www.rockettpedals.com or call us at 760-419-1345. No other warranty is expressed or implied.