

Polyphony: 1 voice

Preset Patch: 384 (128 x 3 BANK)

### **User Memory**

Patch: 128

Pattern: 128

Song: 16

### **Oscillators**

OSC 1, OSC 2, OSC 3 (OSC 3 is also available as LFO)

Waveform: Triangle, Sawtooth, Triangle + Sawtooth (OSC 1, 2 only), Reverse sawtooth (OSC 3 only), Square 1–3

### **Controllers**

Common Section:

VALUE knob

Tempo LED

MODE select switch

FUNCTION select buttons

1–16 buttons

Display

MANUAL button

CONTROL Section:

GLIDE knob

TYPE switch

WHL MIX knob

OSCILLATORS section

[VCO 1]

RANGE knob

TUNE knob

WAVEFORM knob

[VCO 2]

RANGE knob

FINE knob

WAVEFORM knob

[VCO 3]

RANGE knob

FINE knob

WAVEFORM knob

SYNC switch

ENV1 knob

KYBD switch

XMOD TO MW switch

XMOD section

O2-FILTER knob

O3-O2 knob

O3-PW1, 2 knob

MIXER section

OSC1 knob

OSC2 knob

OSC3 knob

FEEDBACK knob

NOISE knob

FILTER/ENVELOPES section

[FILTER]

CUTOFF knob

EMPHASIS knob

KEY TRACK 1/3, 2/3 switch

CONTOUR knob

MTRIG switch

NORM/INVERT switch

[FILTER ENVELOPE]

ATTACK knob

DECAY knob

SUSTAIN knob

[AMP ENVELOPE]

ATTACK knob

DECAY knob

SUSTAIN knob

REL switch

LFO/GATE switch

Gate LED

LFO section

RATE knob

OSC knob

WAVE knob

FILTER knob

MWHL switch

MODE switch

SYNC switch

DELAY section

TIME knob

REGEN knob

AMOUNT knob

---

Effect: Delay

Connectors: Stereo miniature phones jack

OUTPUT jack: Stereo miniature phone type

EXT INPUT jack: Miniature phone type

VCF CV INPUT jack: Miniature phone type

CV INPUT jack: Miniature phone type

GATE INPUT jack: Miniature phone type

TRIGGER IN jack: Miniature phone type

TRIGGER OUT jack: Miniature phone type

MIDI connectors (IN, OUT)

USB port: Micro B type (Audio, MIDI)

Power Supply: AC adaptor (PSB-1U)

Current Draw: 2 A

Accessories: Owner's Manual, Leaflet "USING THE UNIT SAFELY", AC adapter, Power cord

Dimensions (WxDxH): 300 mm x 128 mm x 46 mm

Weight (Excluding AC adapter):</b> 950g