

GK-88 SLIM Size Chart

Akai	MPK88										
Alesis	FUSION 8HD	QS8.2									
Arturia	KeyLab 88										
Casio	140	140S	CDP-100	Privia Pro PX-560	Privia Pro PX-560	Privia PX-160	Privia PX-360	PS20	PX-100	PX110	
	PX-120	PX-130	PX-150	PX-200	PX-3	PX-300	PX-310	PX-320	PX-330	PX-350	
	PX500L	PX-55									
Clavia	NORD STAGE 88										
Korg	B1 Digital Piano	Pa1X PRO	Pa1X PRO ELITE	S170s	SP170	SP-200	SP-250	SP-300	SP-500	TRITON EXTREME 76	
Kurzweil	Artis SE	SP2XS	SP-88	SP54-8							
Nord	Piano 2 HA88	Piano 4	Piano 88	Stage 2 EX 88	Stage 2 HA88	Stage 3 88	STAGE 88				
Roland	EXR-7	FANTOM X7	FP-2	FP-2C	FP-30	FP-4	FP4BK	FP4C-BK	FP4C-WT	FP-4F	
	FP4WH	FP-5	FP-50	FP-5C	FP-7	FP-7F					
StudioLogic	Acuna88	Numa Nano	SL 990XP	SL880PRO	SL-990PRO	VMK188	VMK-88+				
Yamaha	CP33	P-140	P-255	P-45	P-60	P-60S	P-70	P-85	P-95		