



DD90 FIRMWARE UPDATE

INSTRUCTIONS

1. Download the firmware update from our website - <https://www.gear4music.com/driver-downloads>
2. You will download a file called DPUPDATE.BIN, copy it to the root directory of a compatible memory stick and insert into the DD90.
3. Press the 'SETUP' button and scroll down to 'UPDATE'. Press the OK button. Wait for 10 seconds, the system will then begin updating.
4. The DD90 will show a progress bar and automatically update the firmware. Do not turn the unit off during this process.
5. After the DD90 restarts the firmware will be updated, you can press 'setup' and scroll down to version to confirm.



If you have any more questions about this product, please do not hesitate to contact the Gear4music Customer Service Team on: **+44 (0) 330 365 4444** or **info@gear4music.com**