

DIGITAL DRUM KITS

COMPARISON CHART

JDD200



The JDD200 is a high-quality instrument for young beginners to learn the drums from an early age. It comprises a full, 8-piece configuration with all mesh drum pad heads and a control module. Assembly is quick and easy, taking a matter of minutes. Its compact, foldaway design makes it perfect for home use and reassembly time and time again. USB and MIDI connections mean you can connect this kit to a computer for recording, composition or use as a MIDI controller.

DD400



The DD400 has a super compact frame, making it ideal for bedrooms, small studios or practice spaces. A headphone output and a quiet kick drum pedal means you can practice without disturbing the neighbours. USB and MIDI connections mean you can connect this kit to a computer for recording, composition or use as a MIDI controller.

DD400X



The DD400X mesh head profile offers the quietest possible playing experience. You'll be able to play at all hours of the day without disturbing your neighbours. Not to mention, these mesh heads offer a much more authentic drumming experience than standard rubber pads. USB and MIDI connections mean you can connect this kit to a computer for recording, composition or use as a MIDI controller.

DD420X



Take your drumming to the next level with all mesh pads. With a bounce that cannot be matched with rubber pads, the DD420X brings you closer to an acoustic kit. The DD420X offers 3 mesh toms and a mesh snare drum plus a crash, ride, hi-hat cymbals and a bass drum full kick pad. USB and MIDI connections can connect this kit to a computer for recording, composition or use as a MIDI controller.

PADS

SNARE	1x 8" Snare Pad (single trigger)	1x 8" Snare Pad (single trigger)	1x 8" Snare Mesh Pad (single trigger)	1x 8" Snare Mesh Pad (single trigger)
TOMS	3x 6" Tom Pads (single trigger)	3x 8" Tom Pads (single trigger)	3x 8" Tom Mesh Pads (single trigger)	3x 8" Tom Mesh Pads (single trigger)
HI HAT	1x Hi Hat Pad (single trigger)	1x Hi Hat Pad (single trigger)	1x Hi Hat Pad (single trigger)	1x Hi Hat Pad (single trigger)
CRASH	1x Crash Pad (single trigger)	1x Crash Pad (single trigger)	1x Crash Pad (single trigger)	1x Crash Pad (single trigger) with choke
RIDE	1x Crash Pad (single trigger)	1x Ride Pad (single trigger)	1x Ride Pad (single trigger)	1x Ride Pad (single trigger)
BASS DRUM PEDAL	Kick Drum Control Pedal	Kick Drum Control Pedal	Quiet Kick Drum Control Pedal	Full kick pad (single trigger), pedal included
HI HAT PEDAL	Hi Hat Control Pedal	Hi Hat Control Pedal	Hi Hat Control Pedal	Hi Hat Control Pedal

SPECIFICATIONS

VOICES	-	108	108	108
PRESET KITS	38	10	10	10
EDITABLE USER KITS	-	-	-	-
SONG PATTERNS	44	40	40	40
EFFECTS	-	-	-	-
EQUALISER	-	-	-	-
METRONOME	Yes	Yes	Yes	Yes
DISPLAY	3 Digit LED	3 Digit LED	3 Digit LED	3 Digit LED
POLYPHONY	64	64	64	64
RECORD FUNCTION	-	-	-	-
CONTROLS	Power Switch, Master Volume Knob, Data Knob, Kit, Song, Click/Metronome, Tempo, Play/Stop	Power Switch, Master Volume Knob, Start/Stop, Click/Demo, Mode/Tempo Increase, Page/Tempo Decrease, +/- Buttons	Power Switch, Master Volume Knob, Start/Stop, Click/Demo, Mode/Tempo Increase, Page/Tempo Decrease, +/- Buttons	Power Switch, Master Volume Knob, Start/Stop, Click/Demo, Mode/Tempo Increase, Page/Tempo Decrease, +/- Buttons
CONNECTIONS	Headphones, LINE IN, Stereo Out, L/MONO, USB/MIDI, 9V DC Power	Headphones, Aux In, Stereo Out, USB, MIDI Out, 9V DC Power	Headphones, Aux In, Stereo Out, USB, MIDI Out, 9V DC Power	Headphones, Aux In, Stereo Out, USB, MIDI Out, 9V DC Power

DD450+

The DD450+ drum module is a big step up - it comes with a teaching function, a metronome and reverb, as well as a whole host of realistic voices and kits. It's equally suitable for beginners and advanced drummers. The MIDI connectivity means you can record your playing on a sequencer or trigger software on your PC or Mac.

DD470X

The DD470X is a mesh head kit, that offers a realistic playing experience. Ideal for beginners, this drum module features 10 great sounding preset kits, 203 separate drums sounds, as well as a coaching mode for honing rhythm and timing skills. The mesh drum heads utilise a unique non contact technology with adjustable sensitivity for a truly authentic practicing experience, that builds skills that can be transferred to an acoustic kit with ease

DD480X

The DD480X combines mesh drum heads and wooden shells to provide a great sounding kit suitable for beginners and professionals alike. With a completely versatile drum module, you are able to fully customise 30 kits, as well as mix each pad's volume individually. Also with a metronome and coaching mode, this drum kit not only provides an authentic playing experience but can be used to improve your skills as a drummer no matter your level.

PADS

SNARE	1x Mesh Snare Pad (dual trigger)	1x 8" Mesh Snare Pad (dual trigger)	1x 10" Mesh Snare Pad (dual trigger)
TOMS	3x Tom Pads (single trigger)	3x 8" Mesh Tom Pads (dual trigger)	1x 10" 2x 8" Mesh Tom Pads (dual trigger)
HI HAT	1x Hi Hat Pad (single trigger)	1x Hi Hat Pad (dual trigger)	1x Hi Hat Pad (dual trigger)
CRASH	1x Crash Pad (single trigger) with Choke	1x Crash Pad (dual trigger) with Choke	1x Crash Pad (dual trigger) with Choke
RIDE	1x Ride Pad (dual trigger) with Choke	1x Ride Pad (dual trigger) with Choke	1x Ride Pad (dual trigger) with Choke
BASS DRUM PEDAL	Kick Drum Pedal & Pad	Pedal + 1x 8" Mesh Kick Pad	Pedal + 1x 8" Mesh Kick Pad
HI HAT PEDAL	Hi Hat Control Pedal	Hi Hat Control Pedal with Half Open Feature	Hi Hat Control Pedal with Half Open Feature

SPECIFICATIONS

VOICES	310	203	470
PRESET KITS	24	10	30
EDITABLE USER KITS	11	10	30
SONG PATTERNS	60	38	38
EFFECTS	Reverb	-	-
EQUALISER	-	-	-
METRONOME	Yes	Yes	Yes
DISPLAY	3 Digit LED	Backlight LCD	Backlight LCD
POLYPHONY	64	64	64
RECORD FUNCTION	-	Yes	Yes
CONTROLS	2x Headphones, Aux In, Aux Out, MIDI In, MIDI Out, USB Out, 12V DC Power	Power switch, Cursor Buttons, Voice, Rotary Dial, Volume Knob, Song, Play/Pause, Tempo, Metronome, Coach, Mute, REC, Home, Return, Function Buttons, Setup	Power, Cursors, Voice, Rotary, Home, Song, Play/Pause, Setup, Metronome, Coach, Mute, REC, Volume Slider x6, Function Buttons, Master Vol., Phone Vol., Aux In Vol.
CONNECTIONS	Headphones, Aux In, Stereo Out, MIDI In/Out, Power, USB, 9V DC Power	Headphones, Stereo Out, Aux In, MIDI In/Out, USB MIDI, DC In	Headphones, MIDI In/Out, Stereo Out, Aux In, DC In