# **OWNER'S MANUAL**

# DS-3 CLassic distortion



# NUX www.nuxefx.com

Thank you for selecting the NUX products! NUX DS-3 is a distortion box with intuitive control, good dynamic and correct frequency range. It delivers smooth, classic distortion sounds for blues and rock music.


## Precaution

Before using this unit please read the SAFETY INSTRUCTIONS carefully.

# Installing The Battery

A battery is supplied with the unit. Connect the snap cord to the battery and insert the battery as shown in the drawing. When the battery runs down the sound will change. In

such case please replace with new battery. The power comes on when you insert the plug into the IN jack. The use of an AC adaptor is recommended



as the unit's power consumption is relatively high.

# Overview

- Analog Circuit
- Classic Distortion Sound
- ●Level, Gain, Tone
- True-Bypass
- Powered by 9V Battery or Optional Adaptor


# **Specifications**

- Input: IN jack (6.35mm, Mono)
- Output: OUT jack (6.35mm, Mono)
- Power: 9V battery or external AC adaptor delivering 9V DC regulated minimum 300mA ( ⊕ ⊕ )
- Dimensions: 121(L) X 77(W) X 48(D) mm
- Weight: 280g

# Accessories

- ●9V battery
- Owner's manual

# Product Interface



#### 1. POWER IN

Connect a 9V (Negative Tip) adaptor. Optional NUX ACD-008A is recommended.

**NOTE:** Using other adaptor may cause damage or noise.

## 2. LEVEL knob

Set the output level of the DS-3.

#### 3. GAIN knob

Set the distortion amount.

#### 4. TONE knob

Set the treble level.

#### 5. IN jack

This is the input jack for plugging the guitar or the output of another pedal.

# 6. OUT jack

This output the effect to a guitar amplifier or the input of another pedal.

#### 7. LED Indicator

This indicator lights up when the pedal is enabled.

#### 8. ON/OFF Switch

This foot switch is used to turn effect on/off.

- \*Start by setting the GAIN, TONE knobs to the middle position, and increase the LEVEL gradually from zero until you get proper volume.
- \*Fine-tune the GAIN and TONE knobs to find the tone you like.

# WARNING!-IMPORTANT SAFETY INSTRUCTIONS BEFORE CONNECTING. READ INSTRUCTIONS

WARNING: To reduce the risk of fire or electric shock, do not expose this appliance to rain or moisture

**CAUTION:** To reduce the risk of fire or electric shock, do not remove screws. No user-serviceable parts inside. Refer servicing to qualified service personnel.



The lightning symbol within a triangle means "electrical caution!" It indicates the presence of information about operating voltage and potential risks of electrical shock.

The exclamation point within a triangle means "caution!" Please read the information next to all caution signs.

#### THE FCC REGULATION WARNING (for U.S.A.)

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna
- Increase the separation between the equipment and receiver.
   Connect the equipment into an outlet on a circuit different from
- Connect the equipment into an outlet on a circuit different froi that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

# CE mark for European Harmonized Standards

CE Mark which is attached to our company's products of Battery mains the product is in fully conformity with the harmonized standard(s) EN 61000-6-3:2007+A1:2011 & EN 61000-6-1:2007 Under the Council Directive 2004/108/EC on Electromagnetic Compatibility.

- Do not place near heat sources, such as radiators, heat registers, or appliances which produce heat.
- 2. Guard against objects or liquids entering the enclosure.
- 3. Refer all servicing to qualified service personnel.
- Prolonged listening at high volume levels may cause irreparable hearing loss and/or damage. Always be sure to practice "safe listening".

Follow all instructions and heed all warnings KEEP THESE INSTRUCTIONS!



Made in China

© 2015 Cherub Technology-All rights reserved. No part of this publication may be reproduced in any form without prior written permission of Cherub Technology.

# 使用说明书

# **DS-3**

# **CLASSIC DISTORTION**

经典失真模拟效果器



# NUX

www.nuxefx.com

# 感谢您选择NUX的产品!

NUX DS-3是一款操作直观、拥有良好动态和适合频响范围的失真单块。它可以为蓝调和摇滚类型的音乐提供平滑、经典的失真音色。


# 电池更换

当出现下列情况之一时,请更换电池:

1.指示灯变暗; 2.在效果状态下指示灯不亮;

3.声音变弱、失真严重时。

更换方法见下图:



▲ 注意:1.更换电池时,请注意电池的极性。

- 2. 为延长电池的使用寿命,请在不使 用设备时,将连接线从IN接口拔出。
- 3. 若要长期放置产品,请把电池取出以防止电池漏液对产品造成破坏。
- 4. 必须使用相适应的交流电源适配器 (9V,⊕-**€**-⊝)。

# 产品特点

- ●纯模拟电路
- ●经典失真音色
- ●音量、增益、音色调节
- ●硬件直通设计
- ●可用9V电池或选配电源适配器供电


# 技术规格

- ●输入: IN接口 (6.35mm单声道输入)
- 输出: OUT接口 (6.35mm 单声道输出)
- ●体积: 121(L) X77(W) X48(D) mm
- ●重量: 280g

# 随机附件

- ●操作说明书
- ●9V电池

# 产品界面



# 1. 交流适配器插口

交流转稳定直流的9伏适配器,需外正内负型。

## 2. LEVEL旋钮

设定DS-3效果器的总输出音量。

## 3. GAIN旋钮

设定失真量,顺时针旋转,增加失真;逆时针旋转,减少失真。

#### 4. TONE旋钮

调节高频量。顺时针旋转,增加高频量;逆时针旋转,减少高频量。

#### 5. IN输入插口

将电吉他的输出或者前一个效果器的输出连接到 这个接口。

## 6. OUT输出插口

可以连接至电吉他功放或下一个效果器的输入接口

## 7. LED指示灯

指示效果器状态。灯亮,表示效果开启;灯灭, 表示直通状态。

## 8. 效果激活踏板(真直通)

激活效果器或切换到直通状态。

- \*建议先把GAIN、TONE旋钮开到中间位置,把 LEVEL从0的位置开始慢慢开大,直到得到合适的 音量。
- \*调节GAIN和TONE旋钮直到得到满意的音色。

# 注意事项

- ●使用环境:
- 1、避免在高温、潮湿、零下等恶劣的环境中使用。
- 2、避免在强光下使用。
- ●请勿自行拆卸本机。
- 请保存好本手册以便以后查阅。

# 质量承诺

## 亲爱的NU×用户:

在您使用 № 平品时,请仔细参阅产品说明书,当您有疑问和困难时,请拨打售后服务热线:400-990-9866

- 一周内出现质量问题可退货退款
- 一月内出现质量问题可调换
- 一年内出现质量问题可免费维修
- ■终身享有咨询和维修服务

[请向销售商索取有效购买凭证并予以保存]

## 换修政策

#### 一、包换政策:

- 1、消费者自购机之日起1个月之内,在正常使用情况下,出现非人为的产品性能故障,且产品外观及包装保持完好的可向所购机的经销商换机。
- 2、消费者在换机时应出示由经销商开出的购机收据及保修卡,否则经销商可以不予更换。

#### 二、保修政策:

产品在购买之日起1年内,可免费享有维修服务;对于超过1年的产品及人为或不可抗力因素造成损坏的产品,我司可提供有偿维修服务。

广东省珠海市金鼎镇科技九路10号 珠海市蔚科科技开发有限公司 售后服务部 邮编:519085

