

www.modemachines.com

MM-2 OVERDRIVE

Precautions

PLEASE READ CAREFULLY BEFORE PROCEEDING

Powers upply

Please connect the designated AC adapter to an AC outlet of the correct voltage

Please be sure to use only an AC adapter which supplies

 $9V(+/\text{-}10\%)DC.center\ minus\ . The maximum working voltage not exceed$ 12 V. otherwise may be dangerous equipment damage, fire or other problems. Unplug the AC power adapter when not using or during electrical storms.

Always turn off the power of this and all other equipment before connecting or disconnecting, this will help prevent malfunction and / or damage to other

Also make sure to disconnect all connection cables and the power cord before moving this unit.

Handling

Do not apply excessive force to the switches or controls.

Do not let paper, metallic, or other objects into this unit.

Take care not to drop the unit, and do not subject it to shock or excessive pressure.

Cleaning

Clean only with a soft, dry cloth. If necessary, slightly moisten the cloth. Do not use abrasive cleanser, cleaning alcohol, paint thinners, wax, solvents. Cleaning fluids, or chemical-impregnated wiping cloths.

Interference with other electrical devices

Radios and televisions placed nearby may experience reception interference. Operate this unit at a suitable distance from radios and televisions.

To avoid deformation, discoloration, or other serious damage, do not expose this unit to the following conditions;

.Direct sunlight

.Heat sources

.Magnetic fields .Excessive dusty or dirty location

Extreme temperature or humidity .High humidity or moisture

.Strong vibration or shocks

Mainfeatures

- .Round and smooth overdrive tone, excellent dynamic response and
- .Full metal shell
- Very small and exquisite
- .True bypass
- .DC 9V Adapter power supply

Panelinstruction

1. On/Off Switch:

Change the status of the effects from Off to On. 2.ON/OFFL ED:

Instructs effects or bypass status of M2, when the LED is lit up, the effects is on

3.DCINP ower Jack:

For power supply, use a 9-volt DC regulated AC adapter(plug polarity is positive on the barrel and negative in the center)

4.INPUTJack:

1/4" mono audio jack. For connecting guitar 5.OUTPUTJack

1/4" mono audio jack, outputs the signal 6.I OWK nob:

The Lows control emphasizes the lowest octave of a 6-string guitar and the lowest two octaves of a bass guitar.

7.LEVELK nob:

Level control will allow the user to adjust the volume to match the bypass

8.HIGHK nob:

The Highs control brings out the high end harmonics without affecting the fundamental string frequencies. This adds brilliance, bite, and crispness to the sound.

9. GAINK nob:

Adjust the gain of the overdrive sound.

Specifications

Input: 1/4" monaural jack (impedance: 470k Ohms)

8

Output: 1/4" monaural jack (impedance: 470 Ohms)
Power Requirements: AC adapter. 9V DC (center minus plug)

Current Draw: 40mA
Dimension: 46 (W) *94 (D) *50 (H) mm

Accessories: Ower's Manual



www.modemachines.com

Disclaimer: Any specification's update won't be amended in this manual