

## MM-6 PHASER

### Precautions

#### PLEASE READ CAREFULLY BEFORE PROCEEDING

##### Power supply

Please connect the designated AC adapter to an AC outlet of the correct voltage .

Please be sure to use only an AC adapter which supplies 9V(+/-10%)DC,center minus .The maximum working voltage not exceed 12V,otherwise may be dangerous equipment damage,fire or other problems. Unplug the AC power adapter when not using or during electrical storms.

##### Connections

Always turn off the power of this and all other equipment before connecting or disconnecting ,this will help prevent malfunction and / or damage to other devices.

Also make sure to disconnect all connection cables and the power cord before moving this unit.

##### Handling

Do not apply excessive force to the switches or controls.

Do not let paper,metallic,or other objects into this unit.

Take care not to drop the unit,and do not subject it to shock or excessive pressure.

##### Cleaning

Clean only with a soft,dry cloth. If necessary ,slightly moisten the cloth.

Do not use abrasive cleanser,cleaning alcohol ,paint thinners,wax,solvents.

Cleaning fluids,or chemical-impregnated wiping cloths.

##### Interference with other electrical devices

Radios and televisions placed nearby may experience reception interference. Operate this unit at a suitable distance from radios and televisions.

##### Location


To avoid deformation,discoloration,or other serious damage,do not expose this unit to the following conditions;

- |                                    |                                  |
|------------------------------------|----------------------------------|
| .Direct sunlight                   | .Heat sources                    |
| .Magnetic fields                   | .Extreme temperature or humidity |
| .Excessive dusty or dirty location | .High humidity or moisture       |
| .Strong vibration or shocks        |                                  |

### Main features

- \* 100% analog circuit design
- \* Works well with bass, keyboards and even vocals
- \* Total (true) bypass
- \* DC 9V Adapter power supply

### Panel instruction



1. Speed knob controls overall effect rate
2. On/Off Switch:  
Change status from Off to On.
3. DC IN Power jack:  
For power supply, use a 9V DC regulated AC adapter( plug polarity is positive on the barrel and negative in the center).
4. INPUT Jack:  
1/4" mono audio jack, for connecting guitar.
5. OUTPUT Jack:  
1/4" monaural jack,for connecting guitar.

### Specifications

Input: 1/4" monaural jack (impedance: 1 M ohms)  
Output: 1/4" monaural jack( impedance: 10k ohms)  
Nominal Input Level: -20dBV  
Nominal Output Level: -20dBV  
Power Requirements: 9 volts DC  
Current Draw: 5mA  
Dimensions:46 (W) \*94 (D) \*50 (H) mm  
Accessories: Owner's manual